



Allows milk to flow into the bottle

Find matching products on the specifications tab

The valve allows the transferring of milk from the pump into the bottle.

Ease of using Philips spare parts

• Easy renew your product with original Philips parts

Valve SCF160/06

Specifications

Country of origin England **Development stages** Stages: 0 - 6 months

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-04-09 Version: 9.0.1

12 NC: 0000 000 00000

www.philips.com

